

# INSTALLATION INSTRUCTIONS HC8800 & 12-HC8800 Rim Exit Mounting Shims

FOR INSTALLATION ASSISTANCE CALL SARGENT AT 1-800-727-5477 • [www.sargentlock.com](http://www.sargentlock.com)

# SARGENT®

# ASSA ABLOY

### IMPORTANT:

All HC8800 and 12-HC8800 Exit Devices must be installed with the shims between the chassis, mounting bracket and door. Use the chassis and mounting bracket screws provided. When thru-bolting ET trim use the (2) 1/4-20 x 2-7/8" screws provided.

